



AZR-30a PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003686	MAIN BODY	609	26090005	CLICK GEAR
102	21020007	BUSHING	610	26100042	DRAG WASHER
102-1	21020006	BUSHING	611	26110015	EARED WASHER
105	21050012	PINION BEARING FIXED PLATE	612	26120030	KEY WASHER
105-1	21056571	PINION BEARING FIXED PLATE	612-1	26120054	KEY WASHER
108	21081338	CAP	612-3	26120032	KEY WASHER
200	22003612	SIDE PLATE	613	26130011	CLICKRETAINER
201	22010849	SIDE PLATE DECORATION	616	26160038	DRAG RUBBER RING
201-1	22010848	MAIN BODY DECORATION	700	27000318	DRIVE GEAR
201-2	22010013	SIDE PLATE DECORATION	702	27020759	PINION GEAR
201-3	22010015	MAIN BODY DECORATION	705	27050099	TRANSMISSION GEAR
202	22020019	CLICK PAWL	708	27080089	OSCILLATING SLIDER
300	23005102	ROTOR	709	27090003	"C" RETAINER
301	23011625	BAIL ARM	718	27180736	MAIN SHAFT
304	23042508	BAIL ARM COVER	800	28000333	ANTI-REVERSE/ANTI-RE LEVER
305	23050141	KICK LEVER	800-1	28000324	ANTI-REVERSE/ANTI-RE LEVER
306	23060955	BAIL HOLDER COVER	801	28010024	ANTI-RE LEVER SPRING
307	23071427	BAIL HOLDER	0910525	0910525	BALL BEARING
309	23090002	BAIL ARM SLIDER	0910049	0910049	BALL BEARING
310	23100005	COMPRESSION SPRING	0920376	0920376	WASHER
313	23131451	BAIL WIRE ASSY.	0920154	0920154	WASHER
315	23150022	LINE ROLLER	0930058	0930058	SCREW
316	23160002	LINE ROLLER BUSHING	0930541	0930541	SCREW
318	23180005	ROTOR NUT	09301462	09301462	SCREW
400	240015638	SPOOL ASSY.	0930982	0930982	SCREW
407	24070009	EXTENSION SPRING	0930438	0930438	SCREW
500	25006269	HANDLE ASSY.	0930544	0930544	SCREW
504	25040004	HANDLE SCREW CAP WASHER	09301265	09301265	SCREW
513	25130780	HANDLE CAP	0930307	0930307	SCREW
600	26001923	DRAG KNOB	0930429	0930429	SCREW
602	26020006	DRAG SPRING	0930838	0930838	SCREW
607	26070021	DRAG KNOB HOLDER	0930663	0930663	SCREW
608	26080006	DRAG WASHER			