



### BE-30 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003967	MAIN BODY	702	27020759	PINION GEAR
105	21050012	PINION BEARING FIXED PLATE	705	27050099	TRANSMISSION GEAR
105-1	21056571	PINION BEARING FIXED PLATE	708	27080096	OSCILLATING SLIDER
108	21081336	CAP	716	27160008	OSCILLATION SLIDER PLATE
200	22004304	SIDE PLATE	718	27180703	MAIN SHAFT
201	22010447	SIDE PLATE DECORATION	719	27190025	CLICK GEAR
201-1	22010448	MAIN BODY DECORATION	722	27220009	CLICK GEAR WASHER
201-2	22010449	SIDE PLATE DECORATION	800	28000333	ANTI-REVERSE/ANTI-RE LEVER
201-3	22010450	MAIN BODY DECORATION	800-1	28000324	ANTI-REVERSE/ANTI-RE LEVER
300	23005099	ROTOR	801	28010024	ANTI-RE LEVER SPRING
301	23011895	BAIL ARM	0910632	0910632	BALL BEARING
304	23042508	BAIL ARM COVER	0910039	0910039	BALL BEARING
305	23050141	KICK LEVER	0910049	0910049	BALL BEARING
306	23060955	BAIL HOLDER COVER	0910091	0910091	BALL BEARING
307	23071489	BAIL HOLDER	0910015	0910015	BALL BEARING
309	23090002	BAIL ARM SLIDER	0910215	0910215	BALL BEARING
310	23100005	COMPRESSION SPRING	0920310	0920310	WASHER
313	23131372	BAIL WIRE ASSY.	0920376	0920376	WASHER
315	23150023	LINE ROLLER	0920154	0920154	WASHER
318	23180005	ROTOR NUT	0930433	0930433	SCREW
400	240011888	SPOOL ASSY.	0930541	0930541	SCREW
405	24050042	DRAG WASHER RETAINER	0930471	0930471	SCREW
407	24070009	EXTENSION SPRING	09301252	09301252	SCREW
500	25005765	HANDLE ASSY.	0930209	0930209	SCREW
504	25040004	HANDLE SCREW CAP WASHER	0930046	0930046	SCREW
513	25130694	HANDLE CAP	0931002	0931002	SCREW
600	26002816	DRAG KNOB ASSY.	0930544	0930544	SCREW
610	26100011	DRAG WASHER	09301263	09301263	SCREW
611	26110005	EARED WASHER	0930307	0930307	SCREW
612	26120007	KEY WASHER	0930430	0930430	SCREW
612-3	26120032	KEY WASHER	0930840	0930840	SCREW
700	27000318	DRIVE GEAR	0930663	0930663	SCREW