



CLX-302La PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001654	MAIN BODY ASSY	703	17030006	WORM SHAFT GUARD
105	11050006	WORM SHAFT BUSHING	704	17040036	LINE GUIDE SUPPORT BAR
105-1	11050007	WORM SHAFT BUSHING	705	17050013	TRANSMISSION GEAR
117	11170012	RETAINER NUT	706	17060009	TRANSMISSION GEAR
200	12001187	HANDLE SIDE PLATE	707	17070004	TRANSMISSION GEAR
201	12010057	ANTI-RE PAWL	710	17100058	LINE GUIDE ASSY
207	12070092	HOLDED PLATE	712	17120020	WORM SHAFT
208	12080078	SIDE PLATE COVER	713	17130004	LINE GUIDE PAWL CAP
211	12110021	ANTI-RE PAWL PIN	715	17150009	LINE GUIDE PAWL
215	12150015	HOLD PLATE BUSHING	800	18000014	CLUTCH SHAFT
216	12160001	ANTI-RE PAWL SPRING	801	18010007	CLUTCH SPRING
300	13001004	VICE SIDE PLATE	802	18020001	CLUTCH BAR
302-3	13020002	WASHER	804	18040001	CLUTCH SLIDER
303	13030005	CLICK BUTTON	805	18050001	PINION GEAR YOKE
304	13040001	CLICK PAWL	806	18060001	YOKE SPRING
305	13050007	CLICK PAWL SPRING	29000006	29000006	C RETAINER
311	13110074	SIDE PLATE COVERS	29000001	29000001	E RETAINER
400	14000282	SPOOL ASSY.	19010001	19010001	C RETAINER
401	14010026	SPOOL CLICK GEAR	0910227	0910227	BALL BEARING
500	15000467	HANDLE ASSY.	0910248	0910248	BALL BEARING
516	15160002	HANDLE NUT RETAINER	0920157	0920157	WASHER
600	16000093	CAST CONTROL CAP	0920076	0920076	WASHER
609	16090004	DRAG SPRING WASHER	0920166	0920166	WASHER
610	16100038	DRAG WASHER	0920066	0920066	WASHER
610-1	16100045	DRAG WASHER	0920283	0920283	WASHER
611	16110006	EARED WASHER	0930900	0930900	SCREW
612	16120027	KEY WASHER	0930651	0930651	SCREW
612-1	16120029	KEY WASHER	0930577	0930577	SCREW
614	16140003	DRAG WASHER	0930732	0930732	SCREW
615	16150021	STAR DARG	0930609	0930609	SCREW
617	16170023	DRIVE GEAR SHAFT BUSHING	0930196	0930196	SCREW
617-1	16170018	DRIVE GEAR SHAFT BUSHING	0930219	0930219	SCREW
700	17000200	DRIVE GEAR	0930202	0930202	SCREW
701	17010079	DRIVE GEAR SHAFT ASSY	0930226	0930226	SCREW
702	17020322	PINION GEAR	0940025	0940025	O RING