



DRG-55 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003976	MAIN BODY	612-2	26120050	KEY WASHER
105	0910332	PINION BEARING FIXED PLATE	700	27000328	DRIVE GEAR
105-1	0910395	BALL BEARING PLATE	702	27020435	PINION GEAR
108	21081352	CAP	705	27050100	TRANSMISSION GEAR
200	22004307	SIDE PLATE	708	27080097	OSCILLATING SLIDER
201	22010049	SIDE PLATE DECORATION	716	27160009	OSCILLATION SLIDER PLATE
201-1	22010050	MAIN BODY DECORATION	718	27180701	MAIN SHAFT
201-2	22010640	SIDE PLATE DECORATION	719	27190025	CLICK GEAR
201-3	22010641	MAIN BODY DECORATION	722	27220009	CLICK GEAR WASHER
300	23004841	ROTOR	725	27250020	TRANSMISSION GEAR BUSHING
301	23011935	BAIL ARM	800	28000256	ANTI-REVERSE/ANTI-RE LEVER
304	23042513	BAIL ARM COVER	800-1	28000330	ANTI-REVERSE/ANTI-RE LEVER
305	23050145	KICK LEVER	801	28010039	ANTI-RE LEVER SPRING
306	23060958	BAIL HOLDER COVER	0910487	0910487	BALL BEARING
307	23071537	BAIL HOLDER	0910402	0910402	BALL BEARING
309	23090030	BAIL ARM SLIDER	0910091	0910091	BALL BEARING
310	23100069	COMPRESSION SPRING	0920545	0920545	WASHER
313	23131376	BAIL WIRE ASSY.	0920151	0920151	WASHER
315	23150023	LINE ROLLER	0920150	0920150	WASHER
316	23160002	LINE ROLLER BUSHING	0930044	0930044	SCREW
318	23180001	ROTOR NUT	0930575	0930575	SCREW
400	240015023	SPOOL ASSY.	0930171	0930171	SCREW
405	24050031	DRAG WASHER RETAINER	0930945	0930945	SCREW
407	24070006	EXTENSION SPRING	0930046	0930046	SCREW
412-1	24120022	SPOOL BUSHING	0930763	0930763	SCREW
500	25005905	HANDLE ASSY.	0930471	0930471	SCREW
504	25040004	HANDLE SCREW CAP WASHER	0930544	0930544	SCREW
513	25130830	HANDLE CAP	09301274	09301274	SCREW
600	26002816	DRAG KNOB ASSY.	0930643	0930643	SCREW
610	26100055	DRAG WASHER	09301015	09301015	SCREW
611	26110021	EARED WASHER	09301085	09301085	SCREW
612	26120049	KEY WASHER	0930623	0930623	SCREW
612-1	26120056	KEY WASHER			