



### ENB-40 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003613	MAIN BODY	702	27020340	PINION GEAR
102	21020002	BUSHING	705	27050107	TRANSMISSION GEAR
102-1	21020004	BUSHING	708	27080086	OSCILLATING SLIDER
108	21080982	CAP	709	27090003	"C" RETAINER
200	22003373	SIDE PLATE	718	27180517	MAIN SHAFT
202	22020018	CLICK PAWL	719	27190029	CLICK GEAR
300	23003779	ROTOR	722	27220009	CLICK GEAR WASHER
301	23011629	BAIL ARM	725	27250020	TRANSMISSION GEAR BUSHING
304	23043794	BAIL ARM COVER	726	27260016	CLUTCH CAM
305	23050089	KICK LEVER	727	27270031	CLUTCH BAR
307	23071303	BAIL HOLDER	728	27280003	CLUTCH SPRING
309	23090002	BAIL ARM SUPPORT PIN	729	27290017	CLUTCH SLIDER
310	23100005	COMPRESSION SPRING	730	27300015	PINION GEAR YOKE
313	23131058	BAIL WIRE ASSY.	731	27310002	CLUTCH BLOCK SPRING
315	23150022	LINE ROLLER	800	28000242	ANTI-REVERSE/ANTI-RE LEVER
316	23160002	LINE ROLLER BUSHING	800-1	28000322	ANTI-REVERSE/ANTI-RE LEVER
318	23180005	ROTOR NUT	801	28010024	ANTI-RE LEVER SPRING
400	240011717	SPOOL ASSY.	804	28040044	ANTI-RE. PAWL
405	24050001	DRAG WASHER RETAINER	808	28080044	RATCHET BUSHING
407-1	24070038	EXTENDED SPRING	809	28090017	SILENT SPRING
500	25005149	HANDLE ASSY.	0910049	0910049	BALL BEARING
513	25130180	HANDLE CAP	0920150	0920150	WASHER
515	25150002	HANDLE SCREW CAP WASHER	0920335	0920335	WASHER
600	26000181	DRAG KNOB ASSY.	0930417	0930417	SCREW
600-1	26001161	DRAG KNOB	0930574	0930574	SCREW
602	26020003	DRAG SPRING	0930236	0930236	SCREW
607	26070039	DRAG KNOB HOLDER	0930608	0930608	SCREW
609	26090014	CLICK GEAR	0930170	0930170	SCREW
610	26100015	DRAG WASHER	09301029	09301029	SCREW
610-1	26100009	DRAG WASHER	0930437	0930437	SCREW
611	26110037	EARED WASHER	09301264	09301264	SCREW
611-1	26110024	EARED WASHER	0930638	0930638	SCREW
612	26120003	KEY WASHER	0930966	0930966	SCREW
612-1	26120056	KEY WASHER	0930215	0930215	SCREW
616	26160029	DRAG RUBBER RING	0930836	0930836	SCREW
619	26190023	KNOB RETAINER	0930662	0930662	SCREW
700	27000305	DRIVE GEAR			