



FPR-30 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004168	MAIN BODY	611	26110014	EARED WASHER
102	21020007	BUSHING	612	26120028	KEY WASHER
102-1	21020006	BUSHING	612-1	26120054	KEY WASHER
105	21050046	PINION BEARING FIXED PLATE	612-3	26120032	KEY WASHER
108	21081338	CAP	613	26130011	CLICKRETAINER
200	22003612	SIDE PLATE	616	26160038	DRAG RUBBER RING
201	22010622	SIDE PLATE DECORATION	700	27000318	DRIVE GEAR
201-1	22010623	MAIN BODY DECORATION	702	27020759	PINION GEAR
201-2	22010013	SIDE PLATE DECORATION	705	27050099	TRANSMISSION GEAR
201-3	22010015	MAIN BODY DECORATION	708	27080089	OSCILLATING SLIDER
202	22020019	CLICK PAWL	709	27090003	"C" RETAINER
300	23004950	ROTOR	718	27180736	MAIN SHAFT
301	23011625	BAIL ARM	800	28000333	ANTI-REVERSE/ANTI-RE LEVER
304	23042508	BAIL ARM COVER	800-1	28000345	ANTI-REVERSE/ANTI-RE LEVER
305	23050141	KICK LEVER	801	28010024	ANTI-RE LEVER SPRING
306	23060955	BAIL HOLDER COVER	804	28040037	ANTI-RE LEVER PIN
307	23071427	BAIL HOLDER	808	28080042	RATCHET
309	23090002	BAIL ARM SLIDER	809	28090017	SILENT SPRING
310	23100005	COMPRESSION SPRING	0910049	0910049	BALL BEARING
313	23131451	BAIL WIRE ASSY.	0920376	0920376	WASHER
315	23150010	LINE ROLLER	0920154	0920154	WASHER
316	23160002	LINE ROLLER BUSHING	0930417	0930417	SCREW
318	23180005	ROTOR NUT	0930539	0930539	SCREW
400	240014986	SPOOL ASSY.	09301463	09301463	SCREW
500	25005900	HANDLE ASSY.	09301029	09301029	SCREW
513	25130780	HANDLE CAP	0930437	0930437	SCREW
515	25150002	HANDLE SCREW CAP WASHER	0930543	0930543	SCREW
600	26001923	DRAG KNOB	09301264	09301264	SCREW
602	26020006	DRAG SPRING	0930642	0930642	SCREW
607	26070021	DRAG KNOB HOLDER	0930428	0930428	SCREW
608	26080006	DRAG WASHER	0930636	0930636	SCREW
609	26090005	CLICK GEAR	0930836	0930836	SCREW
610	26100042	DRAG WASHER	0930662	0930662	SCREW