



### FPR-40 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004175	MAIN BODY	611	26110014	EARED WASHER
102	21020002	BUSHING	612	26120028	KEY WASHER
102-1	21020004	BUSHING	612-1	26120054	KEY WASHER
105	21056568	PINION BEARING FIXED PLATE	613	26130011	CLICKRETAINER
108	21081361	CAP	616	26160038	DRAG RUBBER RING
200	22003845	SIDE PLATE	700	27000322	DRIVE GEAR
201	22010636	SIDE PLATE DECORATION	702	27020431	PINION GEAR
201-1	22010637	MAIN BODY DECORATION	705	27050105	TRANSMISSION GEAR
201-2	22010029	SIDE PLATE DECORATION	708	27080086	OSCILLATING SLIDER
201-3	22010031	MAIN BODY DECORATION	709	27090003	"C" RETAINER
202	22020019	CLICK PAWL	718	27180523	MAIN SHAFT
300	23004935	ROTOR	725	27250020	TRANSMISSION GEAR BUSHING
301	23011622	BAIL ARM	800	28000242	ANTI-REVERSE/ANTI-RE LEVER
304	23042509	BAIL ARM COVER	800-1	28000322	ANTI-REVERSE/ANTI-RE LEVER
305	23050146	KICK LEVER	801	28010024	ANTI-RE LEVER SPRING
306	23060956	BAIL HOLDER COVER	804	28040044	ANTI-RE LEVER PIN
307	23071441	BAIL HOLDER	808	28080044	RATCHET
309	23090002	BAIL ARM SLIDER	809	28090017	SILENT SPRING
310	23100005	COMPRESSION SPRING	0910049	0910049	BALL BEARING
313	23131452	BAIL WIRE ASSY.	0920376	0920376	WASHER
315	23150010	LINE ROLLER	0920154	0920154	WASHER
316	23160002	LINE ROLLER BUSHING	0930998	0930998	SCREW
318	23180005	ROTOR NUT	0930574	0930574	SCREW
400	240015003	SPOOL ASSY.	0930170	0930170	SCREW
500	25009989	HANDLE ASSY.	09301029	09301029	SCREW
513	25130780	HANDLE CAP	0930543	0930543	SCREW
515	25150002	HANDLE SCREW CAP WASHER	09301264	09301264	SCREW
600	26001923	DRAG KNOB	0930640	0930640	SCREW
602	26020006	DRAG SPRING	0930966	0930966	SCREW
607	26070021	DRAG KNOB HOLDER	0930636	0930636	SCREW
608	26080006	DRAG WASHER	0930836	0930836	SCREW
609	26090005	CLICK GEAR	0930638	0930638	SCREW
610	26100042	DRAG WASHER			