



PLR-55 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004173	MAIN BODY	612	26120049	KEY WASHER
102	21020002	BUSHING	612-1	26120056	KEY WASHER
105	0910332	PINION BEARING FIXED PLATE	612-2	26120050	KEY WASHER
105-1	0910395	BALL BEARING PLATE	700	27000328	DRIVE GEAR
108	21081352	CAP	702	27020435	PINION GEAR
200	22004405	SIDE PLATE	705	27050100	TRANSMISSION GEAR
201	22010632	SIDE PLATE DECORATION	708	27080097	OSCILLATING SLIDER
201-1	22010633	MAIN BODY DECORATION	716	27160009	OSCILLATION SLIDER PLATE
201-2	22010021	SIDE PLATE DECORATION	718	27180701	MAIN SHAFT
201-3	22010023	MAIN BODY DECORATION	719	27190025	CLICK GEAR
300	23004741	ROTOR	722	27220009	CLICK GEAR WASHER
301	23011777	BAIL ARM	725	27250020	TRANSMISSION GEAR BUSHING
304	23042513	BAIL ARM COVER	800	28000255	ANTI-REVERSE/ANTI-RE LEVER
305	23050145	KICK LEVER	800-1	28000330	ANTI-REVERSE/ANTI-RE LEVER
306	23060958	BAIL HOLDER COVER	801	28010039	ANTI-RE LEVER SPRING
307	23071463	BAIL HOLDER	0910487	0910487	BALL BEARING
309	23090030	BAIL ARM SLIDER	0910402	0910402	BALL BEARING
310	23100069	COMPRESSION SPRING	0920545	0920545	WASHER
313	23131449	BAIL WIRE ASSY.	0920151	0920151	WASHER
315	23150022	LINE ROLLER	0920150	0920150	WASHER
316	23160002	LINE ROLLER BUSHING	0930044	0930044	SCREW
318	23180001	ROTOR NUT	0930575	0930575	SCREW
400	240014999	SPOOL ASSY.	0930171	0930171	SCREW
405	24050031	DRAG WASHER RETAINER	0930945	0930945	SCREW
407	24070006	EXTENSION SPRING	0930471	0930471	SCREW
500	25009985	HANDLE ASSY.	0930544	0930544	SCREW
504	25040004	HANDLE SCREW CAP WASHER	09301272	09301272	SCREW
513	25130788	HANDLE CAP	0930643	0930643	SCREW
600	26002816	DRAG KNOB ASSY.	0930763	0930763	SCREW
610	26100055	DRAG WASHER	0930819	0930819	SCREW
611	26110021	EARED WASHER	0930623	0930623	SCREW