



PLRP-40 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004172	MAIN BODY	702	27020822	PINION GEAR
105	21050027	PINION BEARING FIXED PLATE	705	27050105	TRANSMISSION GEAR
105-1	21050036	PINION BEARING FIXED BUSHING	708	27080095	OSCILLATING SLIDER
108	21081351	CAP	716	27160007	OSCILLATION SLIDER PLATE
200	22004404	SIDE PLATE	718	27180704	MAIN SHAFT
201	22010630	SIDE PLATE DECORATION	719	27190025	CLICK GEAR
201-1	22010631	MAIN BODY DECORATION	722	27220009	CLICK GEAR WASHER
201-2	22010029	SIDE PLATE DECORATION	725	27250020	TRANSMISSION GEAR BUSHING
201-3	22010031	MAIN BODY DECORATION	800	28000241	ANTI-REVERSE/ANTI-RE LEVER
300	23004740	ROTOR	800-1	28000322	ANTI-REVERSE/ANTI-RE LEVER
301	23011776	BAIL ARM	801	28010024	ANTI-RE LEVER SPRING
304	23042509	BAIL ARM	0910495	0910495	BALL BEARING
305	23050146	KICK LEVER	0910039	0910039	BALL BEARING
306	23060956	BAIL HOLDER COVER	0910049	0910049	BALL BEARING
307	23071462	BAIL HOLDER	0910091	0910091	BALL BEARING
309	23090002	BAIL ARM SLIDER	0910015	0910015	BALL BEARING
310	23100005	COMPRESSION SPRING	0920540	0920540	WASHER
313	23131452	BAIL WIRE ASSY.	0920376	0920376	WASHER
315	23150010	LINE ROLLER	0920154	0920154	WASHER
318	23180005	ROTOR NUT	0930043	0930043	SCREW
400	240015109	SPOOL ASSY.	0930574	0930574	SCREW
405	24050042	DRAG WASHER RETAINER	0930170	0930170	SCREW
407	24070009	EXTENSION SPRING	09301253	09301253	SCREW
500	25009984	HANDLE ASSY.	0930624	0930624	SCREW
504	25040004	HANDLE SCREW CAP WASHER	0930054	0930054	SCREW
513	25130788	HANDLE CAP	0930471	0930471	SCREW
600	26002816	DRAG KNOB ASSY.	0930543	0930543	SCREW
610	26100015	DRAG WASHER	09301264	09301264	SCREW
611	26110004	EARED WASHER	0930642	0930642	SCREW
612	26120003	KEY WASHER	0930967	0930967	SCREW
612-1	26120054	KEY WASHER	0930836	0930836	SCREW
612-2	26120004	KEY WASHER	0930638	0930638	SCREW
700	27000322	DRIVE GEAR			