



PP-30 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003589	MAIN BODY	612-3	26120032	KEY WASHER
105	21050012	PINION BEARING FIXED BUSHING	700	27000318	DRIVE GEAR
105-1	21056571	PINION BEARING FIXED PLATE	702	27020759	PINION GEAR
108	21081393	CAP	705	27050099	TRANSMISSION GEAR
200	22003500	SIDE PLATE	708	27080096	OSCILLATING SLIDER
201	22010041	SIDE PLATE DECORATION	716	27160008	OSCILLATION SLIDER PLATE
201-1	22010042	MAIN BODY DECORATION	718	27180703	MAIN SHAFT
201-2	22010013	SIDE PLATE DECORATION	719	27190025	CLICK GEAR
201-3	22010015	MAIN BODY DECORATION	722	27220009	CLICK GEAR WASHER
300	23004996	ROTOR	800	28000333	ANTI-REVERSE/ANTI-RE LEVER
301	23011793	BAIL ARM	800-1	28000324	ANTI-REVERSE/ANTI-RE LEVER
304	23042541	BAIL ARM COVER	801	28010024	ANTI-RE LEVER SPRING
305	23050141	KICK LEVER	0910039	0910039	BALL BEARING
306	23060979	BAIL HOLDER COVER	0910091	0910091	BALL BEARING
307	23071409	BAIL HOLDER	0910632	0910632	BALL BEARING
309	23090002	BAIL ARM SUPPORT PIN	0910049	0910049	BALL BEARING
310	23100005	COMPRESSION SPRING	0920310	0920310	WASHER
313	23131451	BAIL WIRE ASSY.	0920376	0920376	WASHER
315	23150010	LINE ROLLER	0920154	0920154	WASHER
316	23160002	LINE ROLLER BUSHING	0930433	0930433	SCREW
318	23180005	ROTOR NUT	0930541	0930541	SCREW
400	240013782	SPOOL ASSY.	0930471	0930471	SCREW
405	24050042	DRAG WASHER RETAINER	09301252	09301252	SCREW
407	24070009	EXTENSION SPRING	0930209	0930209	SCREW
412-1	24120021	SPOOL BUSHING	0930044	0930044	SCREW
500	25005466	HANDLE ASSY.	0931002	0931002	SCREW
504	25040004	HANDLE SCREW CAP WASHER	0930544	0930544	SCREW
513	25130721	HANDLE CAP	09301265	09301265	SCREW
600	26003399	DRAG KNOB ASSY.	0930307	0930307	SCREW
610	26100011	DRAG WASHER	0930429	0930429	SCREW
611	26110005	EARED WASHER	0930838	0930838	SCREW
612	26120007	KEY WASHER	0930663	0930663	SCREW