



SFR-30 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003727	MAIN BODY	702	27020759	PINION GEAR
105	21050012	PINION BEARING FIXED BUSHING	705	27050099	TRANSMISSION GEAR
105-1	21056571	PINION BEARING FIXED PLATE	708	27080096	OSCILLATING SLIDER
108	21081336	CAP	716	27160008	OSCILLATION SLIDER PLATE
200	22003849	SIDE PLATE	718	27180702	MAIN SHAFT
201	22010041	SIDE PLATE DECORATION	719	27190025	CLICK GEAR
201-1	22010042	MAIN BODY DECORATION	722	27220009	CLICK GEAR WASHER
201-2	22010013	SIDE PLATE DECORATION	800	28000333	ANTI-REVERSE/ANTI-RE LEVER
201-3	22010015	MAIN BODY DECORATION	800-1	28000324	ANTI-REVERSE/ANTI-RE LEVER
300	23005102	ROTOR	801	28010024	ANTI-RE LEVER SPRING
301	23011625	BAIL ARM	910013	910013	BALL BEARING
304	23042508	BAIL ARM COVER	910015	910015	BALL BEARING
305	23050141	KICK LEVER	910039	910039	BALL BEARING
306	23060955	BAIL HOLDER COVER	910091	910091	BALL BEARING
307	23071427	BAIL HOLDER	910632	910632	BALL BEARING
309	23090002	BAIL ARM SUPPORT PIN	910049	910049	BALL BEARING
310	23100005	COMPRESSION SPRING	920310	920310	WASHER
313	23131372	BAIL WIRE ASSY.	920376	920376	WASHER
315	23150022	LINE ROLLER	920154	920154	WASHER
318	23180005	ROTOR NUT	930433	930433	SCREW
400	240013784	SPOOL ASSY.	930541	930541	SCREW
405	24050042	DRAG WASHER RETAINER	930471	930471	SCREW
407	24070009	EXTENSION SPRING	9301252	9301252	SCREW
412-1	24120021	SPOOL BUSHING	930209	930209	SCREW
500	25005368	HANDLE ASSY.	930044	930044	SCREW
504	25040004	HANDLE SCREW CAP WASHER	931002	931002	SCREW
513	25130780	HANDLE CAP	930544	930544	SCREW
600	26002995	DRAG KNOB ASSY.	9301265	9301265	SCREW
610	26100015	DRAG WASHER	930307	930307	SCREW
611	26110005	EARED WASHER	930429	930429	SCREW
612	26120007	KEY WASHER	930838	930838	SCREW
612-3	26120032	KEY WASHER	930663	930663	SCREW
700	27000318	DRIVE GEAR			