



### SFR-80 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003729	MAIN BODY	702	27020343	PINION GEAR
105	0910332	PINION BEARING FIXED PLATE	705	27050073	TRANSMISSION GEAR
105-1	0910396	BALL BEARING PLATE	708	27080069	OSCILLATING SLIDER
108	21081353	CAP	716	27160010	OSCILLATION SLIDER PLATE
200	22003851	SIDE PLATE	718	27180614	MAIN SHAFT
201	22010063	MAIN BODY DECORATION	719	27190005	CLICK GEAR
201-1	22010064	SIDE PLATE DECORATION	722	27220005	CLICK GEAR WASHER
201-2	22010037	SIDE PLATE DECORATION	725	27250019	TRANSMISSION GEAR BUSHING
201-3	22010039	MAIN BODY DECORATION	800	28000256	ANTI-REVERSE/ANTI-RE LEVER
300	23004718	ROTOR	800-1	28000327	ANTI-REVERSE/ANTI-RE LEVER
301	23011623	BAIL ARM	801	28010039	ANTI-RE LEVER SPRING
304	23042514	BAIL ARM COVER	0910015	0910015	BALL BEARING
305	23050136	KICK LEVER	0910494	0910494	BALL BEARING
306	23060959	BAIL HOLDER COVER	0910139	0910139	BALL BEARING
307	23073280	BAIL HOLDER	0910182	0910182	BALL BEARING
309	23090030	BAIL ARM SUPPORT PIN	0910013	0910013	BALL BEARING
310	23100049	COMPRESSION SPRING	0920209	0920209	WASHER
313	23131406	BAIL WIRE ASSY.	0920168	0920168	WASHER
315	23150010	LINE ROLLER	0920169	0920169	WASHER
318	23180008	ROTOR NUT	0920539	0920539	WASHER
400	240013788	SPOOL ASSY.	0930452	0930452	SCREW
405	24050031	DRAG WASHER RETAINER	0930575	0930575	SCREW
407	24070006	EXTENSION SPRING	0930562	0930562	SCREW
412-1	24120018	SPOOL BUSHING	0930945	0930945	SCREW
412-2	24120019	SPOOL BUSHING	0930044	0930044	SCREW
500	25005411	HANDLE ASSY.	0930763	0930763	SCREW
504	25040003	HANDLE SCREW CAP WASHER	0930471	0930471	SCREW
513	25130781	HANDLE SPACER	0930544	0930544	SCREW
600	26002997	DRAG KNOB ASSY.	09301272	09301272	SCREW
610	26100055	DRAG WASHER	0930643	0930643	SCREW
611	26110021	EARED WASHER	0930964	0930964	SCREW
612	26120063	KEY WASHER	0930819	0930819	SCREW
612-2	26120064	KEY WASHER	0930663	0930663	SCREW
700	27000332	DRIVE GEAR			