



SLX-50W PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001988	MAIN BODY ASSY.	612-1	16120105	KEY WASHER
101	11010037	BODY LOAD	613	16130007	COMPRESSION SPRING
102	11020103	BODY FOOT	700	17000409	DRIVE GEAR
103	11030003	SCREW	701	17010311	DRIVE GEAR SHAFT
104	11040001	BODY FOOT NUT	702	17020613	PINION GEAR
107	11070043	LINE GUARD	717	17170004	MAIN SHAFT PIN
108	11080016	HANGER	718	17180371	MAIN SHAFT
108-1	11080030	THE PROTECTION COVER OF REELS LUGS	723	17230007	SILENT SPRING
114	11140005	CLAMP	913	19130002	SPRING WASHER
115	11150006	WUNG SCREW	19000004	19000004	E RETAINER
116	11160003	REEL CLAMP NUTS	19010017	19010017	C RETAINER
117	11170002	RETAINER NUT	0910400	0910400	BALL BEARING
200	12002097	HANDLE SIDE PLATE	0910586	0910586	THRUST BEARING ASSY
201	12010027	ANTI-RE PAWL	0910599	0910599	THRUST BEARING ASSY
203	12030003	CONTROL PIN	0910592	0910592	BALL BEARING
204-1	12040002	COMPRESSION SPRING	0910591	0910591	BALL BEARING
205	12050034	DECORATION PLATE	0910103	0910103	BALL BEARING
206	12060017	STOPPER CAP	0920028	0920028	WASHER
207	12070073	HOLDED PLATE	09201000	09201000	WASHER
208	12080109	SIDE PLATE COVER	0920207	0920207	WASHER
215	12150025	HOLD PLATE BUSHING	0920209	0920209	WASHER
215-1	12150024	HOLD PLATE BUSHING	0920218	0920218	WASHER
215-2	12150021	HOLD PLATE BUSHING	0920319	0920319	WASHER
217	12170013	ANTI-RE PAWL SPRING	0920426	0920426	WASHER
217-1	12170017	ANTI-RE PAWL SPRING	0920481	0920481	WASHER
300	13000620	VICE SIDE PLATE	0920490	0920490	WASHER
303	13030012	CLICK BUTTON	0920504	0920504	WASHER
304	13040019	CLICK PAWL	0920505	0920505	WASHER
305	13050014	CLICK PAWL SPRING	0920511	0920511	WASHER
311	13110102	SIDE PLATE COVERS	0920263	0920263	WASHER
400	14001075	SPOOL	0920004	0920004	WASHER
401	14010036	CLICK GEAR	0920152	0920152	WASHER
405	14050028	SPOOL COVER	0930044	0930044	SCREW
500	15000462	HANDLE ASSY.	0930048	0930048	SCREW
501	15010013	HANDLE NUT	09301052	09301052	SCREW
507	15070033	HANDLE BUTTON	09301088	09301088	SCREW
513	15130026	HANDLE COVER	09301113	09301113	SCREW
516	15160030	HANDLE NUT RETAINER	09301115	09301115	SCREW
600	16000101	CAST CONTROL CAP	09301129	09301129	SCREW
601	16010004	COMPRESSION SPRING	09301130	09301130	SCREW
602	16020049	ADJUST BLOCK	0930129	0930129	SCREW
605	16050211	LEVER DRAG ASSY.	0930196	0930196	SCREW
607	16070092	PINION GUARD	0930211	0930211	SCREW
608	16080008	DRAG WASHER RETAINER	0930646	0930646	SCREW
609	16090020	SPRING WASHER	0930893	0930893	SCREW
611	16110049	DRAG WASHER	0940056	0940056	O RING
612	16120063	KEY WASHER			