



TSR-10S

INDEX	KEY NO	PARTS NO	PARTS NAME	INDEX	KEY NO	PARTS NO	PARTS NAME	INDEX	KEY NO	PARTS NO	PARTS NAME
1	100	11004965	Main body assy.	41	610	16100076	Drag washer	81	920	0920157	Washer
2	100	11004966	Main body assy.	42	610	16100078	Drag washer	82	920	0920207	Washer
3	102	11020115	Body foot	43	611	16110079	Eared washer	83	920	0920283	Washer
4	114	11140037	Clamp	44	612	16120109	Key washer	84	920	0920304	Washer
5	114	11140082	Reel clamp assy.	45	612	16120110	Key washer	85	920	0920439	Washer
6	115	11150025	Clamp screw	46	612	16120111	Key washer	86	920	0920455	Washer
7	116	11160017	Clamp nut	47	615	16150262	Star drag	87	920	0920551	Washer
8	117	11170036	Handle nut	48	616	16160016	Star drag bushing	88	920	0920613	Washer
9	200	12002125	Main side plate assy.	49	619	16190003	Washer	89	920	0920614	Washer
10	201	12010077	Anti-re pawl	50	619	16190007	Washer	90	920	0920620	Washer
11	202	12020049	Ratchet	51	700	17000444	Drive gear	91	920	0920621	Washer
12	207	12070127	Holded plate	52	701	17010328	Drive gear shaft	92	920	0920626	Washer
13	211	12110030	PIN	53	701	17010329	Drive gear shaft assy.	93	920	0920627	Washer
14	216	12160008	Extened spring	54	702	17020646	Pinion gear	94	920	09201005	Washer
15	241	12410005	Compression spring	55	717	17170016	Main shaft pin	95	930	0930095	Screw
16	241	12410007	Compression spring	56	718	17180378	Main shaft	96	930	0930241	Screw
17	242	12420008	Compression spring	57	718	17180379	Main shaft assy.	97	930	09301528	Screw
18	303	13030078	Click button	58	720	17200010	Drive gear shaft bushing	98	930	09301219	Screw
19	304	13040032	Click pawl	59	720	17200011	Drive gear shaft bushing	99	930	09301420	Screw
20	305	13050016	Click pawl spring	60	721	47210004	Drive gear bushing	100	930	09301453	Screw
21	316	33160002	Packing washer	61	724	17240001	Click pawl	101	930	09301458	Screw
22	400	14001111	Spool assy.	62	726	17260011	Drive gear bushing	102	930	09301514	Screw
23	400	14001117	Spool	63	800	18000029	Clutch shaft assy.	103	930	09301521	Screw
24	405	24050004	Drag washer retainer	64	801	18010027	Clutch spring	104	930	09301523	Screw
25	405	24050005	Drag washer retainer	65	802	18020186	Clutch bar assy.	105	940	0940068	Oil seal
26	405	24050008	Drag washer retainer	66	804	18040024	Clutch slider	106	940	0940072	Oring
27	500	15000528	Handle arm assy.	67	805	18050009	Clutch yoke				
28	500	15000541	Handle arm	68	815	18150008	Clutch bar screw				
29	509	15090057	Handle knob	69	900	19000001	"E" retainer				
30	509	15090104	Handle knob assy.	70	901	19010031	"C" retainer				
31	510	15100123	Handle knob rivet	71	902	19020004	Tool				
32	512	15120015	Handle knob cover	72	910	0910204	Bushing				
33	600	16000188	Cast control cap	73	910	0910604	Bearing				
34	600	16000189	Cast control cap	74	910	0910622	Bearing				
35	204	12410007	Compression spring	75	910	0910668	Bearing				
36	604	16040012	Drag click pawl over	76	910	0910667	Bearing				
37	606	26060017	Click pawl	77	912	19120037	Cover				
38	609	16090007	Tensioned washer	78	920	0920078	Washer				
39	609	16090026	Tensioned washer	79	920	0920091	Washer				
40	609	16090028	Tensioned washer	80	920	0920117	Washer				